



CLOUD MONITORING SYSTEM

Cloud Based Temperature Monitoring

The AQ Box system is an online temperature monitoring and alerting device which automatically records and sends temperature data to the cloud for easy viewing and reporting via the AQ Box portal. Users log in with their unique username and password to easily view and download or print reports for any compliance reports required. The AQ box comes standard with all Medisafe Plus refrigeration units or can be fitted to your existing vaccine storage unit.

Dual Temperature Probes

The AQ box is unlike other monitoring devices on the market which measure air temperature only. The AQ box is uniquely equipped with two temperature probes providing accurate measurements of both air temperature and simulated product temperature giving you a more accurate monitoring.

Remote Access

Temperature data is accessed via the AQ box portal on any web-enabled smartphone, tablet or computer from any location.

Each unit comes with 12 months cloud monitoring included.
(Charges applicable after initial 12 months term.)

Text and Email Alerts

Notification of unit temperature breaches and power failure are sent real time via text message and email



Reporting

The AQ Box cloud portal allows users to access reports for their nominated date range for ease of reporting of regulatory requirements. Reports available also include temperature breach duration reporting.

Battery Backup

The AQ box monitoring system is connected to a 10amp power source however if the power is disrupted the built-in backup battery will ensure uninterrupted temperature recording of up to 8 hours* during a power outage.

*Back up times are based on a new unit and will reduce with usage

Supplied by

team medical
supplies

✉ P.O. Box 6245 Dural DC, NSW 2158

☎ 1300 22 44 50

📠 1300 22 44 60

@ info@teammed.com.au

🌐 www.teammed.com.au

www.medisafeplus.com.au

Nationwide Phone: 1 800 658 120