



UPS and Battery Pack



Why Choose us

Medisafe Plus, a division of Avem Quirks, specialises in medical refrigeration and monitoring solutions. Designed and proudly built in Australia since 2010, the Medisafe Family of medical fridges and freezers are purpose-built for vaccine storage and follow the Australian Government Department of Health's 'Strive for 5' vaccine storage guidelines.

A Medisafe Plus medical fridge is feature packed, resulting in a medical storage solution that gives you peace of mind - knowing your products are stored in the safest possible manner.

All Medisafe Plus products are backed by our extensive service network. We have a larger network of technicians than any service provider in Australia and we take pride in the quality and expertise of our service personnel. As a result we can confidently commit to delivering high quality service and support in more locations, more responsively than any other supplier.



UPS and Battery Back-Up

The Medisafe Plus UPS and Battery Pack is specifically designed for Medisafe Plus Medical refrigeration providing extended power back up during a power outage.

Our UPS is rated at 2kVA, which provides sufficient capacity to cope with the draw required to power a 2-door vaccine fridge. The UPS will also regulate power surges, circuit shorts and spikes while providing a consistent power output of 230v at all times



Our UPS and Battery pack provides up to 8 hours run time when attached to a medium sized refrigerated cabinet (average 300L). Units can be combined with an additional battery pack unit (2+) to increase run times of up to 7-8 additional hours per unit.
**Run times are based on a new unit and will reduce with usage.*

Each UPS and Battery Pack comes with a market leading 3-year warranty.

Features

- Protection against power outages
- Protection against power variances
- Protects the contents from spoilage
- Continuity of quality supply
- UPS and battery pack is vertically stackable

Uninterrupted Power Supply

DIMENSIONS (HxWxD)	318 X 192 X 428mm
WEIGHT	11 Kg
BATTERY TYPE	12V7Ah

Local distributor:



supplied by



Team Medical

Phone 1300 22 44 50
 Fax 1300 22 44 60
 info@teammed.com.au
 www.teammed.com.au

BP Medical (WA)

Phone 1300 33 55 60
 Fax 1300 33 55 70
 info@bpmedical.com.au
 www.bpmedical.com.au

Battery Back Up

DIMENSIONS (HxWxD)	318 X 192 X 428mm
WEIGHT	26 Kg
CAPACITY	2kVA
POWER REQUIREMENT	10amp GPA
INPUT VOLTAGE	110VAC-288VAC
INPUT FREQUENCY	40Hz-70Hz
OUTPUT VOLTAGE	230V
THDu	2%(linear)/5% (nonlinear)
NOISE	<45dB@<70% load
BATTERY TYPE/NUM	Battery Pack
PHASE	Single Phase
INPUT PF	0.970
OUTPUT PF	0.9
VOLTAGE REGULATION	+1%
CREST FACTOR	3.1/efficiency 91%
BATTERY VOLTAGE	72VDC
MAX CHARGING CURRENT	1A
INTERFACE	RS232 EPO